Info on Phoenix Contact <u>NanoLC</u> ("<u>Nanoline Series</u>") Programmable Logic Controllers (PLC's) including "<u>Nanonavigator</u>" software JT Wunderlich PhD and Chris Peters

1. Base Unit

2. Communications Option modules

3. Real time Clock

4. Expansion I/O Modules

5. Communications Expansion Modules (Ethernet and SMS Modem)

6. Operator Panel

7. Remote mounting for Operator Panel



Read "Nano quickstart.pdf" in my public folder

<u>Update "Nanonavigator" firmware</u> if necessary – read "UpdatingnanoLC_and_nanoNavigator2630_en_A.pdf" in my public folder

Read Datasheets for "Nanoline Seies" <u>base unit and modules</u> on Dig-key: <u>http://www.digikey.com/catalog/en/partgroup/nanoline-series/50362?mpart=2700453&vendor=277</u>

Read Datasheets for <u>relays</u> ("Phoenix Contact Sockets") on Dig-key: <u>http://www.digikey.com/catalog/en/partgroup/phoenix-contact-sockets/19176</u>

Watch Phoenix Contact video on how to program it with <u>flow charts</u>: <u>https://www.youtube.com/watch?v=qXA2O47rqqw</u>

Then, watch this Phoenix Contact video on how to program it with <u>**Relay Ladder**</u> Logic: <u>https://www.youtube.com/watch?v=i4wJFXCS9OU</u>

NOTE: Supplemental Text on Ladder Logic (copy in Lab), and excerpts and related lecture notes distributed: Frank D. Petruzella, *"Programmable Logical Controllers*," 4th edition, September 3, 2010, McGraw-Hill Science/Engineering/Math, (ISBN: 0073510882). Also, here's a good YouTube video (although not for Phoenix Contact NanoLC): https://www.youtube.com/watch?v=Ei4 HqzUFBs

More info at: http://www.phoenixcontact.com/nanoline

Getting Started

To begin the setup you will need a NanoLC main unit, a USB chord, and the NanoLC software.



(NanoLC)

Start by first plugging the NanoLC into the USB port on the front of the computer. Start the nanoline software by clicking on the icon depicted below.



Once the software starts up the next step is to run the connection wizard to set up the NanoLC.



Adjust the USB port settings if the plc is not detected. If the NanoLC is properly connected you will be able to write code. Once you're in the software the NanoLC as well as any I/O expansions need to be configured. Refer to Appendix A for a list of expansion devices and their use. Click on the icon depicted below to enter the configuration menu.



The voltage needs to be adjusted on the input and output of the expansion devices as well as the NanoLC. Voltage is measured in millivolts. For example if you need the NanoLC to take in 5 volts you would need the high value to be at least 5000.

oject	Venion	Base Unit	Operator Panel
ame:	version		
loName	1 🗟 . 0 🚔	Constant of the second se	
escription/Comments:	Major Minor		
anoLine base unit controller	, 24 V DC input power, 2 analog		
puts, 8 digital inputs, 4 DC	relay outputs, 2 high speed		
ounters (P/N: 2/00464)			nLC-OP1-LCD-032-40(20
		N C-055-024D-081-0408D-05A	Fault Action
			Ignore
		Configure	
themet/GSM	Expansion I/O Modules		
	Module 1	Module 2	Module 3
Constants annuality	CETURES	(Status	(270803
1 (MART			
- Materia			

and the second se			
votinataled	Not installed	Not instaned	Notinstaled
Configure	Configure	Configure	Configure
			OK Can
Mode	el #: nLC-055-024D-08I- ion: nanoLine base unit	04QRD-05A controller, 24 V DC input p	ower. 2
Mod Descript	el #: nLC-055-024D-08I- tion: nanoLine base unit analog inputs, 8 dig high speed counter	04QRD-05A controller, 24 V DC input p gital inputs, 4 DC relay outp rs	ower, 2 uts, 2
Mode Descript Commun	el #: nLC-055-024D-08I- tion: nanoLine base unit analog inputs, 8 dig high speed counter ication Option Module	04QRD-05A controller, 24 V DC input p gital inputs, 4 DC relay outp rs Real-Time Clock	ower, 2 uts, 2
Mode Descript Commun Not Inst	el #: nLC-055-024D-08I- iion: nanoLine base unit analog inputs, 8 di high speed counter ication Option Module talled	04QRD-05A controller, 24 V DC input p gital inputs, 4 DC relay outp s Real-Time Clock Configure	ower, 2 uts, 2
Mode Descript Commun Not Inst	el #: nLC-055-024D-08I- iion: nanoLine base unit analog inputs, 8 dig high speed counter ication Option Module	O4QRD-05A controller, 24 V DC input p gital inputs, 4 DC relay outp rs Real-Time Clock Configure	ower, 2 uts, 2
Mode Descript Commun Not Inst	el #. nLC-055-024D-08I- tion: nanoLine base unit analog inputs, 8 dig high speed counter ication Option Module alled Configure	O4QRD-05A controller, 24 V DC input p gital inputs, 4 DC relay outp rs Real-Time Clock Configure Locale=United States Daylight=None	ower, 2 uts, 2
Mode Descript Commun Not Inst	el #. nLC-055-024D-08I- ion: nanoLine base unit nanolog inputs, 8 de high speed counter ication Option Module alled Configure	O4QRD-05A controller, 24 V DC input p gital inputs, 4 DC relay outp s Real-Time Clock Configure Locale=United States On Encr. Warning	ower, 2 uts, 2
Mod Descript Commun Not Inst	el #, nLC-055-024D-08I- ion: nanoLine base unit analog inputs, 8 diy high speed counter ication Option Module alled Configure	O4QRD-05A controller, 24 V DC input p gital inputs, 4 DC relay outp s Real-Time Clock Configure Locate-Ottos Configure Configure Configure	ower, 2 uts, 2
Modi Descript Commun Not Inst	el #. nLC-055-024D-08I- ion: nanoLine base unit analog input.s. 8 dy high speed counter ication Option Module alled Configure	04QRD-05A controller; 24 V DC input p gital inputs, 4 DC relay outp rs Real-Time Ocok Configure. Loader-United States Daylight Cons Configure. Configure.	ower, 2 uts, 2
Mod Descript Commun Not Inst Analog I Analog I	el #. nLC-055-024D-08I- ion: nanoLine base unit analog inputs. 8 di high speed counter ication Option Module alled • Configure nputs Inpolar (P-10 Vots):	04CRD-05A controller, 24 V DC input p ptal inputs, 4 DC relay outp Real-Time Ook Configure. Loade-Unide Stass Daygin-Nore Co. Error Wanning AIN-1 (Unipolar 0-10 Vol	ower, 2 uts, 2
Modi Descript Commun Not Inst Analog I Analog I	el #. nLC-055-024D-08I- ion: nanoLine base unit analog inputs, 8 di high speed counter ication Option Module alled Configure nputs Inpoler 0-10 Vots): 	O4QRD-05A Controller, 24 V DC input p ptial inputs, 4 DC relay outp Real-Time Clock Real-Time Clock Contended Stass Daylight-More Contended Stass Daylight-More AIN-1 (Unipolar 0-10) Vol Lower Staller 0	ower, 2 uts, 2
Mod Descript Commun Not Inst Analog I Analog I Analog I	el #. nLC-055-024D-08I- ion: namoline base unit analogi nunst. 8 di high speed counter ication Option Module alled	AVARD-05A controller, 24 V DC input p tal inputs, 4 DC relay odd p eachTime Ook Configure. Locale=United Stass Cargingte-Nore Configure. AIN-1 (Unipolar 0-10 Vol Lower Scale: 0	to):
Mod Descript Commun Not Inst Analog II Analog II Analog II Lower Upper	el # nLC-055-024D-08I- ion: nanoLine base unit high speed counter ication Option Module alled Configure nputs Juppolar 0-10 Vots): Scale: 0 +	040RD-05A controller, 24 V DC input p ptal inputs, 4 DC relay oudp Real-Time Clock Localie-United Stass Daylight-Nore Cel Encr Wanney AIN-1 (Unpuder 0-10 Vol Lover Scale: 0 Upper Scale: 4055	over, 2
Mod Descript Commun Not Inst Analog I Analog I Lover Upper	el # .nLC-055-024D-08I- ion: nanoLine base unit analog inputs, 8 dø højs speced counter ication Option Module alled • • Configure puds 	O4QRD-05A Controller, 24 V DC input p ptial inputs, 4 DC relay output Real-Time Clock Real-Time Clock Contended Stass Daylight-Nore ContErnor Warning AIN-1 (Unpoler 0-10 Voi Lower Scale: Upper Scale: Upper Scale: 0 Upper Scale: 0 Upper Scale: 0 Upper Scale: 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	ower, 2 uts, 2
Mod Descript Commun Not Inst Analog M Analog M Analog M Lover Upper	el #. nLC-055-024D-08I- ion: nanoline base unit analog inpats. 8 dh high speed counter ication Option Module alled Configure Configure Scale: 0 Scale: 0 Scale: 4095 Scale: 4005 Scale:	OUGRD-05A Controller, 24 V DC Input p S Real-Time Cook Configure Loose-Unded Stass Configure Loose-Unded Stass Configure AIN-1 (Unipolar 0-10 Vol Lover Scale: Upper Scale: 0 Upper Scale: 4055 High-Speed Counter	over, 2 us, 2
Mod Descript Commun Not Inst Analog I Analog I Analog I Love Upper Hgh-Spi E	el # nLC-055-024D-08I- ion: nanoLine base unit analog inputs, 8 di high speced counter ication Option Module alled Configure routa Lingolar 0-10 Volts): Scale: 0 Scale:	OVORD-05A controller, 24 V DC input p ptal inputs, 4 UC relay ouds Real-Time Clock Locale=United Stass Daylight-Nore Co. Encr. Wanning AIN-1 (Unipolar 0-10 Vol Lover Scale: 0 Upper Scale: 0 High-Speed Counter #11 Enabled: 1	ower, 2 uts, 2
Mod Descript Commun Not Inst Analog I Analog I Analog I Lover Upper High-Spr E	el #. nLC-055-024D-08I- ion: nanoLine base unit analog inputs, 8 dø high speed counter ication Option Module alled • • Configure puts scale: 0 • Scale: 0 • Scale: 0 • Mode: Plaing Edge	OdQRD-05A controller, 24 V DC input p gtal inputs, 4 DC relay outp B Real-Time Clock Locarecontext Locarecontext Daylight-None Configure, AIN-1 (Unipolar 0-10 Vol Lower Scale: Uppe-Scale: Uppe-Scale: High-Speed Courter #1 Enabled: Mode:	ower, 2 uts, 2
Mod Descript Commun Not Inst Analog Ii Analog Ii Analog Ii Lower Upper Hgh-Spa E Match	el #. nLC-055-024D-08I- ion: nanoline base unit analog inpats. 8 dh high speed counter ication Option Module alled Configure Configure Configure Scale: 0 Scale: 0 Scale: 4095 Configure	OUGRD-05A Controller, 24 V DC Input p tal Inputs, 4 DC relay outp tal Inputs, 4 DC relay outp Real-Time Ook Configure Locate-United Stass Drygthe-Nate Configure AIN-1 (Unipolar 0-10 Vol Lower Scale: 0 Upper Scale: 0 Upper Scale: 0 Hgh-Speed Courter #1 Enabled: Riang Match Action: Reset	ta): Edge v & Continue v
Mod Descript Commun Not Inst Analog I Analog I Analog I Lover Upper High-Spi E Match	el # nLC-055-024D-08I- ion: nanoLine base unit analog inputs, 8 di high speced counter ication Option Module alled Configure Pouts Julipolar 0-10 Volts): Scale: 0 Scale: 0 Mode: Riang Edge Mode: Riang Edge Action: Reset & Counter	OVORD-05A Controller, 24 V DC input p to input, 24 V DC input p Real-Time Clock Real-Time Clock Configure. Locale-Ordined Stass Daylight-Nore Configure. Locale-Ordined Stass Daylight-Nore Configure. Locale-Ordinate Stass Daylight-Nore Configure. Locale-Ordinat	over, 2 uts, 2
Mod Descript Commun Not Inst Analog M AltN-0 (Lower Upper High-Spe E Match Output D	el # nLC-055-024D-08I- ion: nanoLine base unit analog inghts, 8 dh ingh speed counter ication Option Module alled • • • • • • • • • • • • • • • • • • •	OLGRID-05A Locativities, 24 V DC Input p gala Inputs, 4 DC Input p gala Inputs, 4 DC Input p gala Inputs, 4 DC Input p Galaxies, 4 DC Inpu	over, 2 us, 2
Mod Descript Commun Not Inst Analog Ig Analog Ig Analog Ig Lower Upper High-Spr E Match Output 0	el # nLC-055-024D-08I- ion: naroLine base unit high specie Counter ication Option Module alled Configure Configure Scale: 0 0 Scale: 0 0 Scale: 0 0 Mode Reing Edge Action: Reset & Continue Action: No Output	OURD-05A controller, 24 V DC input p ptal inputs, 4 DC relay ouds Real-Time Cock Locatications Locatications Difference Cost Firm Wanning AlN-1 (Unpolar 0-10 Vol Lover Scale: Upper Scale: High-Speed Counter #11 Enabled: Match Action: Cutput 1 Action:	ta): Edge v & Continue v tqut v

At this point you can begin to code the NanoLC. Code for the NanoLC is written in flowcharts. There are 7 main types of functional blocks that can be used to control the NanoLC. Refer to Appendix B for a list of the functional blocks and what they're used for.



Once your code is ready you can either simulate the code in the NanoLC software or you can upload the code to the NanoLC if you're more confident. To run the simulation press the button pictured below.



If you want to directly upload the code to the NanoLC press the following button:

If you wish to stop the simulation or code on the NanoLC press the following button.

At this point you are now aware of the basics of the NanoLC. Now before you get started we'll first look at some safety precautions.

Safety

The NanoLC is an industrial microcontroller that is completely capable of manipulating high voltages. There a multiple safety precautions that needs to be followed when using the NanoLC.

1. Leave the NanoLC unplugged as long as possible

While using the NanoLC it's wise to turn the power off whenever possible. Leaving the NanoLC off when plugging things in, writing code, or any other development reduces the risk of damaging the NanoLC and the risk of getting shocked.

2. Check your wiring

Before testing your code on the NanoLC it's always best to look over your wiring. It's easy to wire things up wrong, so checking your wires will reduce your risk of damaging the equipment.

3. Color code your wires

We have both red and black wires available in the lab. Use red for positive connections and black for negative connections. Color coding your wires makes it easier to visualize what your NanoLC is doing.

4. Test with lower voltage first

If you are planning on developing a circuit that uses high voltage it may be a smart idea to first test with a much lower voltage. In case something goes wrong using a lower voltage will decrease the chance of damaging the NanoLC and decrease the chance of someone getting shocked.

5. Simulate your code first

Even though you have the ability to upload and run your code at the same time it isn't always wise to do so. To make sure everything works it's wise to simulate your code first.

6. Make sure there are no live wires

Live wires can result in a painful shock. Make sure you don't leave any wires only connected at one end. Also be sure there are no wire fibers exposed. The wire we use for the NanoLCs is frayed and can easily have exposed strands. If you notice any exposed strands be sure to run the wire through a terminal block first. This will reduce the risk of touching a frayed strand.



Following these safety guide lines will keep you safe while working with the NanoLCs. We do have these in the lab !